

### **Suitable driveway drainage for a dropped kerb**

If your driveway has a gradient that is towards the public highway a linear channel or drain (such as an Aco drain or similar) is required at the highway boundary.

This should be across the frontage of the driveway to intercept any surface water runoff before it reaches the highway.

Example of a linear drain

